



# Degradation of Silica and Sapphire Windows at Elevated Temperatures

N. S. Jacobson

NASA Glenn Research Center/HX5

Cleveland, OH 44135

[nathan.s.jacobson@nasa.gov](mailto:nathan.s.jacobson@nasa.gov)

High Temperature Electromagnetic Materials

National Academies


Washington, DC

March 2-3, 2023



# Degradation of Oxides at High Temperatures

- In general, oxides are the most stable compounds
  - Silica and alumina are especially stable
  - Will not react with ambient oxygen or nitrogen
- But they do degrade at high temperatures
  - Fluxing (dissolution)
    - $\text{SiO}_2(\text{s}) + \text{Na}_2\text{CO}_3 \rightarrow \text{Na}_2\text{SiO}_3(\text{liq}) + \text{CO}_2(\text{g})$
  - Direct vaporization
    - $\text{SiO}_2(\text{s}) \rightarrow \text{SiO}(\text{g}) + \frac{1}{2} \text{O}_2(\text{g})$
    - $\text{SiO}_2(\text{s}) \rightarrow \text{SiO}_2(\text{g})$
  - Enhanced vaporization
    - $\text{SiO}_2(\text{s}) + 2\text{H}_2\text{O}(\text{g}) \rightarrow \text{Si}(\text{OH})_4(\text{g})$
- Measurements/Methods
  - In vacuum
  - In atmosphere—look at higher ambient pressures; effect of enhanced vaporization
  - Computational—basic thermochemical data on vapor species using ab initio methods
- Modeling, predicting behavior




## Vapor Phase may be Complex

- $\text{SiO}_2$ 
  - In vacuum:  $\text{Si(g)}$ ,  $\text{SiO(g)}$ ,  $\text{Si}_2\text{O}_2\text{(g)}$ ,  $\text{SiO}_2\text{(g)}$ ,  $\text{O(g)}$ ,  $\text{O}_2\text{(g)}$
  - With water vapor:  $\text{SiO(OH)}$ ,  $\text{SiO(OH)}_2\text{(g)}$ ,  $\text{Si(OH)}_4\text{(g)}$ ,  $\text{SiO(OH)}_6\text{(g)}$ ,  $\text{Si}_3\text{O}_2\text{(OH)}_8\text{(g)}$
- $\text{Al}_2\text{O}_3$ 
  - In vacuum:  $\text{Al(g)}$ ,  $\text{AlO(g)}$ ,  $\text{Al}_2\text{O(g)}$ ,  $\text{AlO}_2\text{(g)}$ ,  $\text{Al}_2\text{O}_2\text{(g)}$ ,  $\text{Al}_2\text{O}_3\text{(g)}$
  - With water vapor:  $\text{AlO(OH)(g)}$ ,  $\text{AlOH(g)}$ ,  $\text{Al(OH)}_2\text{(g)}$ ,  $\text{Al(OH)}_3\text{(g)}$
- Accurate thermodynamic data for these species allows
  - Calculation of maximum vapor fluxes (material loss rate)
  - Models of applications, where diffusion is limiting. Thermodynamic data is an input to equations.

# Equilibrium vs Langmuir Vaporization into a Vacuum


## • Knudsen Cell



- Obtain near equilibrium between condensed phase/vapor
- First developed by Knudsen (Denmark), 1909: Measure Hg vapor pressures
- Vapor effusing from orifice leads to a weight loss rate which relates to pressure; vapor can also be analyzed with spectrometer


$$J (\text{max}) = \frac{P_{eq}}{\sqrt{2\pi MRT}}$$

## • Free Surface or Langmuir vaporization




- Measure vaporization from flat faces with balance or mass spectrometer
- Closer to application
- Often has a kinetic step, accounted for by vaporization coefficient,  $\alpha$


$$J = \frac{\alpha P_{eq}}{\sqrt{2\pi MRT}}$$



# Measured $\text{SiO}_2$ Knudsen and Free Surface Vaporization Coefficient = 0.035





Kowalski et al., 2022



## Experimental Methods


- Vaporization/degradation in a vacuum
  - Equilibrium/Knudsen or Free Surface/Langmuir
    - Vacuum thermogravimetric methods
      - Simple weight loss
    - High temperature mass spectrometry
      - Identify species and determine their partial pressures
- Vaporization/degradation into atmosphere
  - Reactive or non-reactive atmosphere
    - Flowing gas thermogravimetric methods
      - Simple weight loss
    - Transpiration
      - Get an accurate vapor pressure to determine thermodynamic data
    - High pressure sampling mass spectrometry
      - Identify species

# Vacuum Microbalance—Direct measure flux from a Knudsen Cell (Equilibrium) or Coupon (Free Surface)



- Measure flux ( $\text{mg}/\text{cm}^2\text{-hr}$ )
- $$J = \frac{\alpha P_{\text{eq}}}{\sqrt{2\pi MRT}}$$

# Knudsen Effusion Mass Spectrometer




- Resistance heated cell, Option of leaking small amount of gas into cell

- Measure partial pressures  $P_i = \frac{kI_i T}{\sigma}$




# Different Vapor Species Important at Different Total Pressures: Need Different Experimental Methods




- Thermogravimetric system at higher total pressure
- Transpiration at ambient pressure
- Sampling mass spectrometry

Myers and Jacobson, Calphad, 2018.

# Thermogravimetric Apparatus: NASA "Homemade"



- Larger hot zone  $\Rightarrow$  larger samples
- Wide range of atmospheres possible
  - $\text{H}_2\text{O}(\text{g})$ ,  $\text{CO}_2(\text{g})$ ,  $\text{SO}_2(\text{g})$ ,  $\text{Cl}_2(\text{g})$ , 5% $\text{H}_2/\text{Ar}$




- Silica coupon in 50%  $\text{H}_2\text{O}/\text{O}_2$  (Opila, JACerS, 1997)
- $\text{SiO}_2 + 2 \text{H}_2\text{O}(\text{g}) = \text{Si}(\text{OH})_4(\text{g})$

# Measure Vapor Pressures at high ambient pressures


## Transpiration Method

- Form vapor species, collect deposit downstream, analyze
- Adjust flow rates to assure equilibrium in reaction chamber
- Limited only by deposition rates and deposit analysis technique
  - $\text{SiO}_2$ —easiest! Dissolve deposit in dilute HF and then use ICP-AES ( $\mu\text{g}$ )
  - Other oxides require more involved dissolution procedure (D. Johnson)
- Accurate technique for obtaining thermochemical data at 1 bar
- Used for Si-OH, Cr-OH, Ti-OH in our labs






## Results for $\text{SiO}_2 + \text{H}_2\text{O}$ Van't Hoff Plot: $\ln K$ vs $1/T$



- $\text{Si}(\text{OH})_4$  dominant species; Some evidence of  $\text{SiO}(\text{OH})_2$  at higher temperatures
- For  $\text{Si}(\text{OH})_4$ :  $\Delta_r H(1200 \text{ K}) = (54.6 \pm 2.7) \text{ kJ/mol}$ ;  $\Delta_r S(1200 \text{ K}) = (67.5 \pm 2.1) \text{ J/mol-K}$
- Use computed or measured spectroscopic data to get heat capacities


Jacobson et al. (2005), J. Chem. Therm. 37, 1130-7.

# Sampling Mass Spectrometer




- Uses a free jet expansion to directly sample a one atmosphere process without altering chemistry
  - Gas/solid reaction which generate volatiles
  - Observe condensable species


## First Direct Observations of $\text{Si}(\text{OH})_4(\text{g})$ and $\text{Al}(\text{OH})_3(\text{g})$



Opila et al., JACerS, 1997




Myers and Jacobson, Calphad, 2018.



## Thermodynamic data from Quantum Chemistry Methods (C. Bauschlicher/NASA Ames)

- In conjunction with experimental methods
- DFT and wave function methods
  - DFT—B3LYP gives basic molecular geometries, corrections then needed for internal rotations and anharmonicity
  - Higher level methods for enthalpies
- Input data:  $\Delta_f H^\circ(298)$ ,  $S^\circ(298)$ ,  $C_p$
- Al-O-H, Si-O-H, Zr-O-H, Hf-O-H, Yb-OH, Gd-OH, Y-OH, Cr-O-H, Mn-O-H, La-O-H, Ta-O-H
- Database for computational thermodynamics codes/free energy minimizers: FactSage, ThermoCalc, SOLGASMIX, NASA CEA, etc.




# Predicting Performance in Actual Environments

- Thermodynamic effects of overpressure:
  - $\text{SiO}_2(\text{s}) \rightarrow \text{SiO}_2(\text{g})$  No effect
  - $\text{SiO}_2(\text{s}) \rightarrow \text{SiO}(\text{g}) + \frac{1}{2} \text{O}_2(\text{g})$  Small overpressure of  $\text{O}_2$  will suppress vaporization significantly
- Thermodynamic Modeling
  - Free energy minimizer computer code
  - Input is solid oxide composition and over pressure (e.g.  $\text{O}_2$ ,  $\text{O}$ ,  $\text{H}_2\text{O}$ , etc.)
  - Minimizes free energy of all possible reactant products subject to constraint of mass conservation
  - Gives equilibrium vapor pressure for calculating mass loss
  - *Need accurate thermochemical data for all species*
- Kinetic
  - Static boundary layer which limits flow generally by orders of magnitude
- Surface changes



## Vapor Pressures $\Rightarrow$ Material Loss/Recession Rates




- Vapor pressure  $\Rightarrow$  flux (wt/(unit area-time)) or recession (length/(unit time))
- Inner viscous sublayer in turbulent flow becomes vanishingly thin

Jacobson, et al. (2020) Oxid. Met. 93, 247-82.




$\text{SiO}_2 \rightarrow \text{SiO(g)} + \text{O}_2\text{(g)}$  Vaporization into vacuum, static gas, laminar flow gas, and turbulent flow gas




# Laminar Flow Computational Fluid Dynamics (CFD) Results with Temperature Fixed

## Velocities and $x(\text{SiO})$ , $x(\text{O}_2)$ (M. Kuczmarski, GRC)

### Velocity Vectors



### Concentration of Vapors




- Coupon disturbs flow: Boundary layer
- Distribution of SiO,  $\text{O}_2$  after coupon


Jacobson, et al. (2020) Oxid. Met. 93, 247-82.

## Crystallization of Fused Silica Outer Surface: 8 hrs at Temperature in vacuum


1748K




1798K




1848K



1898K




1948K



- Vaporizing Surface is effectively crystalline silica above 1798K
- XRD: cristobalite

Ingersoll et al., JECerS, 2017

## $\text{Al}_2\text{O}_3$ (sapphire) + $\text{H}_2\text{O}$ Generates Etch Pits





Micrographs of sapphire coupon edges  
after the following exposures: 1450°C, 68%  
 $\text{H}_2\text{O}$ , 72 h.

Opila and Myers, JACerS, 2004.



# Performance in Different Environments: Recession at 1800K (1527C)

Recession of SiO<sub>2</sub>Al<sub>2</sub>O<sub>3</sub> Recession at 1800K (1527C)

- Recession is suppressed by an overpressure of oxygen due to decomposition reaction
  - $\text{SiO}_2(\text{s}) \rightarrow \text{SiO}(\text{g}) + \frac{1}{2} \text{O}_2(\text{g})$
  - $\text{Al}_2\text{O}_3(\text{s}) \rightarrow 2\text{Al}(\text{g}) + \frac{3}{2} \text{O}_2(\text{g})$
- Water vapor may enhance recession, depending on amount and energetics of reaction



# Summary and Conclusions

- Silica and alumina (and other oxides) are very stable thermochemically
  - Still subject to chemical attack
- Routes of chemical attack
  - Dissolution (fluxing) from deposits
  - Vaporization in non-reactive gases
    - Vacuum
    - Flowing Ar
  - Vaporization in reactive gases
    - O<sub>2</sub> (suppresses vaporization in most, but not all cases)
    - H<sub>2</sub>O (enhances vaporization)
- Experimental methods
  - Low ambient pressure: TGA and mass spectrometer
  - High ambient pressure: Transpiration, TGA, sampling mass spectrometer
- Modeling/predicting attack
  - Need a good thermodynamic database and free energy minimizer code
  - Need fluid/environmental parameters
  - Surface changes




## Supplemental Material



# Free Jet Expansion

Atmosphere

Mass Spectrometer  $10^{-8}$  torr  
Preserves Chemical and  
Dynamic Integrity of Process




Miller,  
Science  
(1984)

- Use the mass spectrometer to directly sample vapors from a one atmosphere process
  - Gas/solid reaction—identify hydroxide species

# Vaporization Coefficients

- Vapor Flux leaving a free surface into a vacuum




$$J(\text{max}) = \frac{P_{eq}}{\sqrt{2\pi MRT}}$$



- Modified by a factor  $\alpha$ : Vaporization Coefficient

$$J(\text{max}) = \frac{\alpha P_{eq}}{\sqrt{2\pi MRT}}$$

- Metals: Generally unity; Oxides  $0.1$  to  $10^{-5}$
- Condensation coefficient
  - Vapor flux striking a free surface—only a fraction of the equilibrium flux condenses on an oxide
  - Free surface vaporization = Langmuir vaporization

**REACTION**FactSage<sup>®</sup>**REACTION**FactSage<sup>®</sup>

## MgO (001) Surface after Vaporization at 1873K

